



Connectors

- J1 - Power
 - 1 - GND
 - 2 - Power
- J2 - USB
- J3 - Supported
 - 1 - High (+5V) when supported device detected
 - 2 - GND
- J4 - Unlock
 - 1 - High (+5V) when unlocked
 - 2 - GND
- J5 - User interface
 - 1 - LED blue (power)
 - 2 - LED red (USB activity, Error)
 - 3 - LED green (unlock)
 - 4 - Clear switch terminal 1
 - 5 - Clear switch terminal 2
 - 6 - Power switch terminal 1
 - 7 - Power switch terminal 2
 - 8 - GND



Sheet: /		File: StickLock.sch	
Title: StickLock		(c) copyright richard.prinz@min.at	
Size: A4	Date: 2019-05-24	Rev: A	
KiCad E.D.A. kicad 4.0.7-e2-637658ubuntu16.04.1			Id: 1/1